

AVHub & Multi-cameras Settings

Introduction

AVHub supports connecting multiple cameras for the unified management of video devices. With the Yealink RoomConnect application, you can rename/set the image or set the camera layout of the cameras connected to the AVHub.


How to Use

You can directly use the MTouch II matched with MVC to operate or log in to the Yealink Device Management Platform to operate remotely. For the remote control, please refer to [Remote Control](#).


Before you begin: Connect the AVHub to the camera. For more information, please refer to [AVHub Audio & Video Processor](#).

1. Camera Settings

1. You need to switch the system to Windows Mode (For more information, please refer to [Switch Account](#)).
2. Open the Yealink RoomConnect application and select AVHub card.




3. Select **Image Setting** to set the camera's name or other settings. For the setting parameters, please refer to [Basic Settings](#).




2. Camera Layout

You need to switch the system to Windows Mode (For more information, please refer to [Switch Account](#)).

1. Open the Yealink RoomConnect application and select the AVHub card.



2. Enable **Camera Layout** in **Device Settings**.



3. Adjust Layout in Microsoft Teams Rooms


You need to switch the system to Microsoft Teams mode (For more information, please refer to [Switch Account](#)).

Set Fullscreen Mode

During a call/meeting, the selected camera picture is displayed in full screen.

1. Select **Room Controls** to enter **Camera Layout**.
2. Select **Fullscreen** in **Layout Mode**.

Select **Add** with the mouse or finger to select a camera that has been connected to AVHub.




Setting Division Mode

During a call/meeting, the video screen displays each camera in equal parts. The number of equally divided screens can be set from 2 to 9.

1. Select **Room Controls** to enter **Camera Layout**.
2. Select **Division** in **Layout Mode**.


Select **Add** with the mouse or finger to select a camera that has been connected to AVHub.



Setting Surround Mode


During a call/meeting, the selected camera screen is displayed in the large window and other camera screens are displayed in small windows. The number of N to the can be set from 1 to 8.

1. Select **Room Controls** to enter **Camera Layout**.
2. Select **Surround** in **Layout Mode**. Select **Add** with the mouse or finger to select a camera that has been connected to AVHub.



Adjust Camera Layout During the Meeting

You can go to **Meeting > More > Room Controls** to adjust the camera layout during the meeting.



FAQ

Does the AVHub support connect to the Central Control System?

AVHub's USB connecting solution supports connecting to the central control. For more information, please refer to [Central Control System API Version and Manual](#).

When AVHub is used with VCS system, it does not support central control.