


MVC BYOD-Extender Installation


Package Contents

TIP

We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in poor performance.




(1,5 m, 4,92 ft)
MVC-BYOD-Extender
(with USB -A)



(7,5m, 24,6ft)
CAT5e UTP
(RJ45 - RJ45) Cable




(W25.4*L50mm,3M)
Velcrox2



Quick Start Guide

Install MVC BYOD Extender

1. Stick the velcros on the back of MVC-BYOD-Extender.



2. Put the MVC-BYOD-Extender on a surface such as a table, wall and so on.




Please refer to [MVC BYOD-Extender](#) for more information on how to use it.

Connetction

Connect to the UVCamera

- Connect directly to the UVC camera (UVC40)
- Connect to the UVC camera via PoE switch (UVC84)



Connect to the PC

